


Ant. TA LW MW UKW

	1	2	3	4	5	6	7	8	9	10
a										
b										
c										
d										
e										
f										
g										
h										
i										
j										
k										
l										

leer gelassene Stellen: Gerät „aus“



C:	1, 2,	3, 4,	5, 6, 8, 9,	7, 11, 10, 12, 17, 13, 15, 16, 18, 19,	20,	21,	22,	72,	23, 24, 40, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37,	38, 39, 40, 41,	42, 43, 44,	45, 46, 47,	48, 49,	50,	51, 52,	53, 54,	55, 56, 57,	58, 59,	60,
R:	1,	3,	4, 2,	6,	7,	8,	9,	11, 12, 36,	13,	15,	6,	35,	17, 18, 19, 38, 39, 42, 21,	22,	23, 24, 25,	26,	27, 28, 29, 30, 31, 32,	33,	34,

GRUNDIG WERKE FURTH (BAY.)
„Musikgerät 960 J“